USER'S MANUAL
REMOTE CONTROL **"LSE22"**

CONVENTIONS:
All functions will be referred between "-", keys between (-) and visual indicators [-▲].

INDICATORS
[LED] – visual indicator of function execution;

KEYS
(TV.ON/OFF) – Key to turn on and turn off the TV.
(TV.CHANNEL.+) – Key to increase the TV channel.
(TV.CHANNEL.-) – Key to reduce the TV channel.
(TV.VOLUME.+) – Key to increase the TV volume.
(TV.VOLUME.-) – Key to reduce the TV channel.
(SOUND.ON/OFF) – Key for INPUT selection.
(SOUND.CHANNEL.+) – Key to increase the FM station;
(SOUND.CHANNEL.-) – Key to reduce the FM station;
(SOUND.VOLUME.+) – Key to increase the SOUND volume.
(SOUND. VOLUME.-) – Key to reduce the SOUND volume.
(LIGHT.ON/OFF) – Key to turn on or turn off the LIGHTS;
(LIGHT.CHANNEL1.+) – Key to increase the lightning intensity of zone 1.
(LIGHT.CHANNEL1.-) – Key to reduce the lightning intensity of zone 1.
(LIGHT.CHANNEL2.+) – Key to increase the lightning intensity of zone 2.
(LIGHT.CHANNEL2.-) – Key to reduce the lightning intensity of zone 2.
(*) – Key to turn on or turn off the air conditioning;
(▲) – Key to open the blinds;
(▲) – Key to close the blinds;
(▶) – Key to open the curtain;
(◀) – Key to close the curtain;

1.0 - SPECIFICATIONS

· 5 keys to command the TV with function learning;
· 5 keys to command the sound;
· 5 keys to command 2 illuminations zones;
· 4 keys to command blinds and curtains;
· 1 key for additional function;

2.0 - TECHNICAL CARACTHERISTICS

- Power supply: 2 batteries of 1,5V Lr03 AAA;
- Dimensions: 170x43x18 mm;
- Keys in silicone;
- Plastic box ABS;
- Range up to 6 metres.

3.0- MANUTENTION

1.Clean frontal panel, in case of damage contact authorized reseller.

4.0 - PRECAUTIONS

2.Do not use abrasive cleaners;
3.Do not apply liquids directly;

5.0 - TV SET KEYS

Program the TV SET keys:

*Point the original remote control of the television, to the remote control LSE22, see pic.;
* Press simultaneously keys (SOM.ON/OFF) and (LIGHT.ON/OFF) for 3 seconds;
* [LED] lights on;
* Press (TV.VOLUME.+) key
* [LED] blinks one time;
* Press correspondent key to the increase volume of the original remote control;
* [LED] blinks one time;
* Wait until the [LED] blinks twice as a confirmation of correct code;
* The [LED] remains lighted;
* Proceed the same way for the other keys;
* After programming all television keys, press key (SOM.ON/OFF);
* [LED] blinks two times and all programmed keys remain memorized.

Note: All codes of the programmed keys remain in memory even without batteries.

6.0 - SOUND KEYS

(SOUND.ON/OFF) – Key of INPUT selection in the models Ref. ERAMP1802-S, ERAMPTCL 202-S and ERAMPLCD;

(SOUND.CHANNEL.+) – Key to increase FM station in models Ref. ERAMP1802-S, ERAMPTCL 202-S and ERAMPLCD;

(SOUND.CHANNEL.-) – Key to reduce FM station in models Ref. ERAMP1802-S, ERAMPTCL 202-S and ERAMPLCD;

(SOUND.VOLUME.+) – Key to increase the SOUND volume in the models Ref. ERAMP1802-S, ERAMPTCL 202-S and ERAMPLCD;

(SOUND.VOLUME.-) – Key to reduce the SOUND volume in the models Ref. ERAMP1802-S, ERAMPTCL 202-S and ERAMPLCD.

6.0 - **LIGHT KEYS**

(LIGHT.ON/OFF) – Key to turn on or turn off LIGHTS referring to the designated zones as channel 1 and channel 2, through the installation of the receptor module ref. ERDIMMER for each zone;

(LIGHT.CHANNEL1.+) – Key to increase the luminous intensity of zone 1 through the installation of receptor module Ref. ERDIMMER;

(LIGHT.CHANNEL1.-) – Key to reduce the luminous intensity of zone 1 through the installation of receptor module Ref. ERDIMMER;

(LIGHT.CHANNEL2.+) – Key to increase the luminous intensity of zone 2 through the installation of receptor module Ref. ERDIMMER;

(LIGHT.CHANNEL2.-) – Key to reduce the luminous intensity of zone 2 through the installation of receptor module Ref. ERDIMMER;

NOTE: In case of non-functioning with remote controls check if the dipswitch configuration (pic. 2) of the command ERDIMMER corresponds to the zone of the remote control in use.

6.0 - **BLIND KEYS**

(▲) – Key to open the blinds through the installation of module ERESTORES;
(▼) – Key to close the blinds through the installation of module ERESTORES;

NOTE: In case of non-functioning with remote controls check if the dipswitch configuration (pic. 2) of the command ERESTORES corresponds to the zone of the remote control in use.

6.0 - **CURTAINS KEYS**

(▶) – Key to open the curtain through the installation of module ERCURTAINS;
(◀) – Key to close the blinds through the installation of module ERCURTAINS;

NOTE: In case of non-functioning with remote controls check if the dipswitch configuration (pic. 4) of the command ERCURTAINS corresponds to the zone of the remote control in use.